

Once the ENC file has been downloaded, copy it onto a USB flash drive properly formatted in FAT32.

- Insert the USB device into one of the instrument's USB ports.
- Press the MEDIA button and select the newly inserted device.
- Select the "ENC" file with a double tap on the touchscreen and wait for the installation to complete, without removing the USB drive.
- After the installation is complete, to load the sounds, press MENU > SOUND BANK and select the new .SBK files one at a time with a double tap on the touchscreen.
- Confirm by selecting "YES" and wait for the loading process to complete and for the instrument to reboot.

The new sounds will be available by accessing USER VOICE > the corresponding category, in the last available positions (p. 16/16)