

## How to update the instrument

1. Download file eventdir.zip in the PC.
2. Unzip the file eventdir.zip.
3. A folder eventdir will be created.
4. Inside the folder eventdir you will find a subfolder eventdir.
5. Copy the folder eventdir on the root of an USB pen drive.
6. Safely remove the USB pen drive from PC.
7. Switch off the instrument.
8. Insert the USB pen drive into one of the 2 USB ports.
9. Switch on the instrument and wait for the update to complete.
10. The procedure will restart the instrument several times.
11. Once the update is complete, the initial screen of the instrument will appear.

Warning:

don't turn off the instrument while updating.